


This chart can be printed at scale so you can have it handy when working on your build.

On your print settings make sure you have selected Scale = Actual Size or 100% and that the paper size is set to letter.



OpenBuilds Screw Sizes

