




digital wood joints



# Survey Board Joints

## T-shaped Joints

To open a file of the kind you need, just press the name of the appropriate folder (e. g. → DXF.10).

Name of the joint:

Name of file: in folder:

← Finger Tenons

F\_010 → DXF.10 – 2D → MicroStation → Velum 2.7 → Iges 5 → MBA\_CAD Part 1 → MBA\_SIM Part 1  
→ DXF.12 – 3D → Minicad 7.0 → Velum 4.0 → MBA\_CAD Part 2 → MBA\_SIM Part 2

← Fingertip Tenons with Lateral Positioning Tenons

F\_008 → DXF.10 – 2D → MicroStation → Velum 2.7 → Iges 5 → MBA\_CAD Part 1 → MBA\_SIM Part 1  
→ DXF.12 – 3D → Minicad 7.0 → Velum 4.0 → MBA\_CAD Part 2 → MBA\_SIM Part 2

← Fingertip Tenons with Central Positioning Tenon

F\_009 → DXF.10 – 2D → MicroStation → Velum 2.7 → Iges 5 → MBA\_CAD Part 1 → MBA\_SIM Part 1  
→ DXF.12 – 3D → Minicad 7.0 → Velum 4.0 → MBA\_CAD Part 2 → MBA\_SIM Part 2

← Clip Tenons

C\_001 → DXF.10 – 2D → MicroStation → Velum 2.7 → Iges 5 → MBA\_CAD Part 1 → MBA\_SIM Part 1  
→ DXF.12 – 3D → Minicad 7.0 → Velum 4.0 → MBA\_CAD Part 2 → MBA\_SIM Part 2

← Catch Tenon

C\_002 → DXF.10 – 2D → MicroStation → Velum 2.7 → Iges 5 → MBA\_CAD Part 1 → MBA\_SIM Part 1  
→ DXF.12 – 3D → Minicad 7.0 → Velum 4.0 → MBA\_CAD Part 2 → MBA\_SIM Part 2

